



apek | wall mount

49" • 65" • 75"

TouchSpace family installation manual

## SECURITY INSTRUCTIONS

Read all instructions in this manual carefully. If you have any questions regarding installation, please contact Apek support.

- » The stand and its parts are designed to be assembled with Apek monitors. Apek does not cover damage installed with other monitors.
- » Do not install monitors with a larger weight than recommended.
- » Do not repair the product yourself. Contact technical service for verification and repair.
- » Use the package to store components and spare parts.
- » Do not force the loose parts when assembling, the parts are designed to fit perfectly.
- » Install the product in a flat and stable location.
- » Periodically wipe the stand with a clean, slightly damp cloth (it is not advisable to use chemicals).
- » Do not place or support cleaning products and/or substances on the support which may leak or damage the material.
- » **Be careful when handling the monitor. Support for another person is necessary.**
- » When supporting the monitor with the screen facing down, make sure the surface is adequate not to damage it.
- » The assemble of parts that do not belong to the product is the sole responsibility of the buyer.

## Environment



Apek is a company that cares about the environment. We seek to develop products with the maximum of recyclable materials and with the least environmental impact. Dispose of materials properly.

Packaging materials such as cardboard boxes, bubble wrap, papers, EPS (expanded polystyrene), EPE (Expanded Polyethylene) and bags, are recyclable. Check the type of material for proper disposal in specialized recyclers.

## Warranty

Apek warrants to the customer the support and parts replacement for a period of 12 (twelve) months, considered from the date of issuance of the invoice of purchase, provided that it has been installed according to the guidelines described in the manual installation that comes with the product and only in the national territory.

- » Apek guarantees the product against any defect of material or manufacturing process, since its description fits into a production or bad functioning issue.
- » The replacement of defective parts and maintenance from these services resulting from this warranty will be provided directly at the factory or in technical assistance accredited by Apek.
- » On-site service.
- » Additional support, may be hired additionally. This service is not included in the factory warranty.

## Warranty limitations

Warranty against manufacturing defects does not cover the following items:

- » Installation or use of the product in disagreement with the recommendations in the installation manual.
- » Damage caused by:
  - Inappropriate usage;
  - Overthrowing and accidental actions;
  - Agents of nature;
  - Chemical agents;
  - Inappropriate applications, changes, modification or repair performed by entities not authorized by Apek;
  - Removal and/or modification of serial number or product identification;
- » Use of the product with load (weight) above its capacity;

**Remarks :**

- » Apek assumes no responsibility or liability for the persons or entities that may offer a warranty on its products.
- » Expenses regarding and consequential from the installation of parts that do not belong to the product are the unique responsibility of the buyer.
- » Apek reserves the right to change, technical and aesthetic characteristics of its products without prior notice.
- » The warranty is valid only upon presentation of the invoice for the purchase of this product.


Correctly check the installation location for the stand to be placed in a masonry wall or in a wood panel that has adequate resistance.

Do not attach the stand to the drywall only, make sure the drywall is reinforced to withstand the indicated maximum load.

**WALL MOUNT INSTALLATION**

Compatibility	TouchSpace 49"- 65"- 75"
Vesa pattern	400x400
Height from floor to center of monitor	1400 mm
Position	Horizontal
Maximum weight	100Kg

**Components**




**SETTING ON THE WALL - 1<sup>st</sup> Step**

With the help of another person, Put the stand on the righ position. where you want to install and check that it

Before drilling make sure that the distance between the anchorage bars is correct.


Use both bars to support the monitor.

If necessary mount the stand on the wall by simulating the already positioned hook bars to be sure of the distance between the anchors.




is level.

- 1°** While another person holds the stand in the desired position, mark the 8 fixing points of the screws on the wall.
- 2°** Drill the screw holes with a proper S10 drill size.
- 3°** Remove the excess residue generated from the drill from inside the holes and insert the S10 bushings until they are flush with the wall.



**4°** Position the holder over the holes and fix it using the S10 screws and washers as shown.



Secure the stand using all the fixing points.

After install, make sure the stand is firmly in place to support the monitor.


## 2<sup>nd</sup> Step




### Assemble the hook bar with e monitor lying down.

Support the monitor with the screen down on a smooth and proper surface so that it does not damage it.

Position the bars with their claws facing inward, align their drilling with the drill located in the center of the vertical bars of the monitor. Secure using 4 M6x16 screws.




Use the 4 hooks on both bars to support the monitor.



Before drilling make sure that the distance between the anchorage bars is correct.

Use both bars to support the monitor.

If necessary mount the stand on the wall by simulating the already positioned hook bars to be sure of the distance between the anchors.



**1°** While another person holds the stand in the desired position, mark the 8 fixing points of the screws on the wall.

**2°** Use an S10 bolt to drill the holes over the markings.

## 3<sup>rd</sup> Step



In two people put up the monitor and support the 4 hooks of the bars on the rubberized covers of the anchorage bars.

When supporting, slowly release the monitor by transferring its weight to the stand. If you notice any malfunction, remove the monitor from the stand and contact the authorized technical.


## DRYWALL - 1<sup>st</sup> Step



**Correctly check the installation location for the stand to be placed in a masonry wall or in a wood panel that has adequate resistance.**


**Do not install the stand to the drywall only.**

With the help of another person, position the stand where you want to install and check that it is level.



**3°** Remove the excess residue generated from the drill from inside the holes.

**4°** Position the holder over the holes and fix it using the S10 screws and washers as shown.




**2nd Step**

**Assemble the hook bar with e monitor lying down.**

Support the monitor with the screen down on a smooth and proper surface so that it does not damage it.

Position the bars with their claws facing inward, align their drilling with the drill located in the center of the vertical bars of the monitor. Secure using 4 M6x16 screws.


Use the 4 hooks on both bars to support the monitor.



**3rd Step**

In two people rise the monitor and support the 4 hooks of the bars on the rubberized covers of the anchorage bars.

When supporting, slowly release the monitor by transferring its weight to the stand. If you notice any malfunction, remove the monitor from the stand and contact the authorized technical support.



**SUPPORTE**

If any listed components are damaged or not included in the package; have doubts about installation, features, and operations; and for more information, please contact:



**SAC**

support@apekinternational.com  
www.apekinternational.com